


Multifunction Steering Wheel , (1XT),(1XX),(1XW),(2PF),(2PK),(2ZM),(2ZQ),(2ZS)

From January 2011

**Audi**

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




Steering Column Electronics Control Module

- J527 Steering Column Electronics Control Module
- J623 Engine/Motor Control Module
- ST1 Fuse Panel 1
- ST2 Fuse Panel 2
- SC6 Fuse 6 (On Fuse Panel C)
- SC7 Fuse 7 (On Fuse Panel C)
- SB13 Fuse 13 (On Fuse Panel B)
- T14u 14-Pin Connector, Left Plenum Chamber E-Box Connector Station, Black
- T16e 16-Pin Connector
- T17b 17-Pin Connector, Left Plenum Chamber E-Box Connector Station
- T17f 17-Pin Connector, In the Left A-Pillar Connector Station, White
- T17i 17-Pin Connector, In the Left A-Pillar Connector Station

- 45 Ground Connection Behind Instrument Panel, Center
- 199 Ground Connection 3 (in Instrument Panel Wiring Harness)

- * Refer to Applicable Wiring Diagram for Fuse Positions
- *2 Refer to Applicable Engine Wiring Diagram
- *3 From May 2016
- *4 For Vehicles with Heated Steering Wheel
- *5 From June 2014




- ws = white
- sw = black
- ro = red
- rt = red
- br = brown
- gn = green
- bl = blue
- gr = grey
- li = lilac
- vi = lilac
- ge = yellow
- or = orange
- rs = pink

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

Steering Column Electronics Control Module, Instrument Cluster CAN Bus High Wire Junction 2

- J285 Instrument Cluster Control Module
- J527 Steering Column Electronics Control Module
- T16e 16-Pin Connector
- T17o 17-Pin Connector, In the Connector Station, Right A-Pillar
- T32 32-Pin Connector
- T46b 46-Pin Connector
- TV81 Instrument Cluster CAN Bus High Wire Junction 2
- TV84 Instrument Cluster CAN Bus Low Wire Junction 2
- A204 Instrument Cluster CAN Bus High Connection (in Instrument Panel Wiring Harness)
- A205 Instrument Cluster CAN Bus Low Connection (in Instrument Panel Wiring Harness)
- B708 Instrument Cluster CAN Bus High Connection 1 (in Main Wiring Harness)
- B709 Instrument Cluster CAN Bus Low Connection 1 (in Main Wiring Harness)
- * Data Bus Wire (CAN Bus)



ws = white
 sw = black
 ro = red
 rt = red
 br = brown
 gn = green
 bl = blue
 gr = grey
 li = lilac
 vi = lilac
 ge = yellow
 or = orange
 rs = pink


Steering Column Electronics Control Module, Powertrain CAN Bus High Wire Junction 2

- J527 Steering Column Electronics Control Module
- J533 Data Bus on Board Diagnostic Interface
- T16e 16-Pin Connector
- T17i 17-Pin Connector, In the Left A-Pillar Connector Station
- T32b 32-Pin Connector
- T46a 46-Pin Connector
- T46b 46-Pin Connector
- TV33 Powertrain CAN Bus High Wire Junction
- TV37 Powertrain CAN Bus Low Wire Junction
- TV79 Powertrain CAN Bus High Wire Junction 2
- TV82 Powertrain CAN Bus Low Wire Junction 2

B383 Powertrain CAN Bus High Connection 1 (in Main Wiring Harness)

B390 Powertrain CAN Bus Low Connection 1 (in Main Wiring Harness)

* Data Bus Wire (CAN Bus)



- ws = white
- sw = black
- ro = red
- rt = red
- br = brown
- gn = green
- bl = blue
- gr = grey
- li = lilac
- vi = lilac
- ge = yellow
- or = orange
- rs = pink


Signal Horn Activation, Steering Column Electronics Control Module

- F350 Spiral Spring
- H Signal Horn Activation
- J453 Multifunction Steering Wheel Control Module
- J527 Steering Column Electronics Control Module
- N95 Driver Airbag Igniter
- N250 Driver Airbag Igniter 2
- T1iy 1-Pin Connector
- T1iz 1-Pin Connector
- T1ja 1-Pin Connector
- T2fk 2-Pin Connector
- T4ah 4-Pin Connector
- T4ahx 4-Pin Connector
- T4hc 4-Pin Connector
- T12v 12-Pin Connector
- T4 4-Pin Connector
- Z36 Heated Steering Wheel

1284 Ground Connection 1 (in Steering Wheel Wiring Harness)


- * For Vehicles with Heated Steering Wheel
- *2 Adapter Cable

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



Steering Column Electronics Control Module

- E440 Left Multifunction Buttons on Steering Wheel
- E441 Right Multifunction Buttons on Steering Wheel
- E479 Tiptronic Upshift Button
- E480 Tiptronic Downshift Button
- E522 Steering Wheel Heating Button
- J453 Multifunction Steering Wheel Control Module
- J527 Steering Column Electronics Control Module
- T3di 3-Pin Connector
- T3dj 3-Pin Connector
- T3dk 3-Pin Connector
- T3dl 3-Pin Connector
- T9e 9-Pin Connector
- T9f 9-Pin Connector
- * Adapter Cable




Audi

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

erWin

Lane Assistance Button, Steering Column Electronics Control Module

- E517 Lane Assistance Button
- G428 Heated Steering Wheel Sensor
- J234 Airbag Control Module
- J453 Multifunction Steering Wheel Control Module
- J527 Steering Column Electronics Control Module
- T4ah 4-Pin Connector
- T17p 17-Pin Connector, In the Connector Station, Right A-Pillar
- T100 100-Pin Connector
- * For Vehicles with Lane Assistance



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.